


DING-A-LING

BOXER

INSTRUCTION SHEET


DO NOT THROW THIS SHEET AWAY. READ ALL INSTRUCTIONS CAREFULLY.

HOW TO PLAY WITH YOUR BOXER



1. PRESS LEFT BUTTON TO RAISE LEFT ARM.
2. PRESS RIGHT BUTTON TO RAISE RIGHT ARM.
3. PRESS ONE BUTTON AFTER THE OTHER AND BOXER WILL FIGHT.

IMPORTANT



VASELINE

FOR BEST RESULTS ON SPACE SKYWAY SETS, PUT A SMALL AMOUNT OF VASELINE® ALL ALONG LEDGES BETWEEN DING-A-LING'S FEET, AS SHOWN. BE SURE TO ADD MORE VASELINE® WHEN NEEDED.



©1971 TOPPER CORPORATION, ELIZABETH, N.J. 07206

3018-0030

PRINTED IN U.S.A.